


Outer offset / Poke

Measure from the hub flange face to the inside of your outer wheel arch or wherever you would like the outer wheel rim to stop, this measurement we call – Outer offset or Poke



Inner offset / inset

Measure from the hub flange face in towards the first thing the wheel / tyre will touch, normally your suspension, coil over etc, this measurement we call – inner offset or inset